


DYNAFLAIR




ROLLING CLOSURE LIMIT SWITCH



(FRONT VIEW)



(TOP VIEW)



1st!
PUSH DOWN
RETAINING PLATE
TO RELEASE LIMIT
WHEELS. DO NOT
FORCE WHEELS!
THEY WILL BREAK!

